



## Instructions Non-Stick Hamburger Press

Model Number 38348

### Directions for using your Non-Stick Hamburger Press

1. Disassemble all parts and hand-wash all parts of Patty Press in hot soapy water before first use. Rinse and hand dry immediately. DO NOT allow to air dry and DO NOT wash in dishwasher.
2. Loosen locking wing nut and turn adjustment knob to desired burger thickness, note the thickness on the shaft of the adjustment screw.
3. When desired thickness is adjusted, tighten locking wing nut to ensure consistent results.
4. (Optional) If you are going to freeze patties, use wax paper on the base plate.
5. Using your hands, form hamburger into a ball palm sized ball and place on base or wax paper.
6. Using lip on top of Patty Press, press down on top until it comes into full contact with the base. If meat extrudes from the sides, remove before opening top and adjust the size of your palm sized ball accordingly.

