




2017 Covert Blackhawk Verizon Camera

1. Login to <https://secure.covert-wireless.com>
2. Select new user to create your customized login. For existing users, login with your email address and password.
3. Choose your plan.
4. Enter your personal information and your billing information.
5. Enter your MEID number from the camera. This is to identify the device being activated. It can be found on the outside packaging of your camera as well as the inside sticker of the device.



Downloading the Mobile App:

Search "**Covert Wireless**" in your Google Play Store or Apple App Store. Be sure to turn on notifications on your phone.



Accessing the Web Portal:

Open your web browser to:

www.covert-wireless.com



For more instructions, helpful tips or support, please visit our website at www.covertscoutingcameras.com, email our support staff at support@dlccovert.com or call our toll-free number at 877-462-1799.

Note: You may cancel your monthly plan anytime by calling 877-462-1799, emailing support@dlccovert.com, or logging into the web-portal.