



# Quick Start Guide

## Covert WC30-V LTE Wireless Camera

1. Insert batteries, SD card, and SIM card into your WC30-V.
2. Switch the camera to SETUP and find the Registration menu screen.
3. Using your cell phone camera, scan the QR code and follow the link to [secure.covert-wireless.com](https://secure.covert-wireless.com)
4. Either Login or create a new account.
5. Once logged in, you will see the IMEI and ICCID populated in the appropriate fields.
6. Choose which Verizon plan you would like the camera added to, and click activate

## Downloading the Mobile App:

Search "**Covert Wireless**" in your Google Play Store or Apple App Store. Be sure to turn on notifications in your phone settings.



## Accessing the Web Portal:

Open your web browser to:

[www.covert-wireless.com](http://www.covert-wireless.com)



*Note: You may cancel your monthly plan anytime by calling 270-743-1515, emailing [support@dlccovert.com](mailto:support@dlccovert.com), or logging into your [secure.covert-wireless.com](https://secure.covert-wireless.com) account.*